
DIN Pins scan the selected row
The DIN SRx number is configurable the first one is used for the first 64 keys, a second one can be used for 64 additional keys!
DIN SRx -> D7
DIN SRx -> D6
DIN SRx -> D5
DIN SRx -> D4
DIN SRx -> D3
DIN SRx -> D2
DIN SRx -> D1
DIN SRx -> D0
DOUT SRx -> D7
DOUT SRx -> D6
DOUT SRx -> D4
DOUT SRx -> D3
DOUT Pins select the row
The DOUT SRx number is configurable, the first one is used by default for up to 128 keys (here only 64 are shown)
DOUT SRx -> D4
DOUT SRx -> D2
DOUT SRx -> D1
DOUT SRx -> D0
Wiring Diagram for
MIDIbox KB: up to 64 keys without velocity
Type #1
(C) T. Klose 2012-04-05